

## Quick Setup Guide

**digitalsignage.NET** is a cloud- based digital signage software allowing you to send your message to your screens in just 5 steps. Powering IAdea devices, we offer a simple solution that suits all budgets and needs. To follow the steps below you need a digitalsignage.NET account that can be requested from [here](#).

### Step 1- Connect

Add SMIL HD embedded device



Connect your screen to the IAdea HD player (XMP-3350 Wireless Full HD player) using a VGA or HDMI cable and connect to the Internet.

Add SMIL Smart Photo Frame



Apply mains power to the media device. Ensure you turn on the display.

### Step 2- Configure

Attach a keyboard to the media player. This will access the on-board settings page.



Configure the network settings to connect to your wireless network.

Specify the content source

<http://smil.digitalsignage.net>

Save the settings. The device will now reboot.

**Step 3-** Get your Hex code

Once the device has rebooted the display will show a unique six digit code- the "Hex code".



**Step 5-** Display your content

After having registered your IAdea device, add the media files you wish to display to your digitalsignage.NET portal. Your device is now informing your audience.

**Step 4-** Register

Enter your Hex Code into the Properties box within your [digitalsignage.NET](http://digitalsignage.NET) portal.



The screen will display "Successfully registered".



## Troubleshooting

Problem 1: After configuring the device the screen is blank.

Solution: Please check your wireless network settings and content source settings.

Problem 2: My Hex code remains permanently displayed and does not show "Successfully registered".

Solution: Check that the Hex code settings are correct within your Properties box in digitalsignage.NET.

Problem 3: "Successfully registered" message is permanently displayed.

Solution: Make sure that you have added your media files within the system and have published them.

## Resources

We offer two comprehensive User Guides on how to set up an IAdea device with digitalsignage.NET. Please email us at [info@digitalsignage.net](mailto:info@digitalsignage.net) if you wish to consult them. We will soon launch a How To video that will visually present all the steps you need to take to set up your device.

Request a 30 day free trial of our software and experiment with the technology. Go to <http://info.digitalsignage.net/free-trial/> and fill in the request form.

**Email us at [info@digitalsignage.net](mailto:info@digitalsignage.net) for assistance.**